

GCAT

Classroom Podium User Instructions

➤ POWER ON PODIUM EQUIPMENT

- Verify the main power switch is on



➤ DATA PROJECTOR

- **TO TURN PROJECTOR ON** - Push the **POWER** button on the Pixi SP Control plate that is mounted on the wall near the instructor podium.
- **TO TURN PROJECTOR OFF** – Push the **POWER** button twice. The fan in the projector will continue to run for a few minutes until the unit cools down.
Be sure to verify the projector is off before leaving the room!



➤ TO USE COMPUTER WITH DATA PROJECTOR

- Boot up and log on to computer (no passwords).
- Push the **VGA/AUDIO INPUT #1** (labeled PC) on the Extron MPS112 unit



➤ TO USE DVD/VCR COMBO WITH DATA PROJECTOR

- Push the **VIDEO/AUDIO INPUT #1** (labeled PC) on the Extron MPS112 unit
- On the combo, select DVD to play a DVD or Video to play a VHS tape



➤ VOLUME CONTROL

- Use the volume knob to adjust the volume

