


Tripod





Setting up Tripod


- Open the quick side-lever leg locks to adjust tripod to desired height
- Verify that all legs are locked before mounting camcorder





Mounting Camera/Camcorder

- Remove camera/camcorder from case
- Screw the mounting plate into the bottom of camera/camcorder





Mounting Camera/Camcorder

- Move the quick release lever to “free” position
- Slide mounting plate (which is firmly attached to the camera/camcorder) into place
- Move lever to “locked” position

