

DUO VIDEO

(Simplified Setup)

1. Select the **Instructor Camera** and set the camera the way you want it for the entire class period. This is the Main Source ... students at the *far end* will see this on one screen.
2. Push the **Call Status Control** button



3. Push the **Duo Video Call** button



4. Select the **PC Presenter**. This is the *DUO SOURCE* ... students at both the *local & far end* will see this one the screen

5. Push **Exit** to return to the main operating page



DUO SOURCE = Buttons are gray. Use the sources listed below to view source locally and at the far end.

- VCR/DVD
- PC PRESENTER (computer)
- STUDENT CAMERA

NOTE: The **MAIN SOURCE** (WHAT STUDENTS ON BOTH SITES SEE ALL THE TIME = INSTRUCTOR CAMERA, which was setup in step #1 above. You will not need to push the MAIN SOURCE button unless you need to adjust the Instructor camera.



6. To disconnect Duo video, push the **Call Status Control** button. Then push the **DISC DUO** button.

