

3M Interactive Whiteboard (Menu structure)

Push the **INPUT** button on the 3M remote to see the current settings. To view menu structure, push the **MENU** button on the 3M remote. Use the button on the back of the remote to select/enter.



When using the Tandberg with the 3M Whiteboard, the whiteboard **INPUTS** should be set as follows:

Video: DVI-D
Resolution: 1024 x 768 @ 60HZ
Audio In: RCA
Out: Speakers



Volume		
Mute		
Balance		
Bass		
Treble		
Input	Stereo Mini1	<i>Computer Audio</i>
	Stereo Mini2	
	RCA	<i>Tandberg Audio</i>
Output	Speakers	
Mode	Stereo	
Reset Audio		
Edit Menu		



VGA		<i>Laptop only, connected to wall jack behind cabinet</i>
DVI-D		<i>Tandberg Input</i>
DVI-A		
Composite		
S-Video		
RCA Video	Selected	
	Active	
	No Signal	
Exit Menu		



PIP Active	Off	
Video Swap		
PIP mode		
PIP Input	S-video	
PIP Position	Top Left	
PIP Size	Medium	
Exit Menu		
Exit Menu		



Brightness		-----50-----
Contrast		-----50-----
Sharpness		-----50-----
Detail Enhance		-----0-----
Hue		-----176-----
Color		-----50-----
Aspect Ratio	Standard	Active
Position		
More		
Exit Menu		



Language		
Auto Switch	Input	Off
Auto Switch	PIP	On
Auto Shutoff		-----10-----
On Screen Timer		-----0-----
Splash Screen	Off	
DVI EDID	Digital	
More	→	Blank Color
		Keystone
		Reset Lamp Timer
Exit Menu		



Input	Source DVID	
	Resolution	1024 X 768
	H Freq	48.36KHZ
	V Freq	60HZ
Timers	Lamp Hrs	
	Engine Hrs	
	Sys Hrs	
DCB	Firmware	DP ver 1.1
	OSD	0.85e
	Serial	166-06-119
	IP	0.0.0.0.
	Part#	0