


TV/VCR Combo

Problems	Suggestions
No power	<ul style="list-style-type: none">▪ Verify that the TV/VCR is plugged in to the electrical outlet on the TV cart▪ Verify that the TV cart extension cord is plugged into a wall outlet▪ Verify that the wall outlet is live (try a different wall outlet)
Static on the TV	<ul style="list-style-type: none">▪ Push the TV/VIDEO button on either the TV or the remote 
Video is playing but no audio	<ul style="list-style-type: none">▪ Adjust the volume by using the up/down volume buttons on either the TV or remote 